

BOAT TOP USE & CARE



Bimini Tops

- Be certain to secure all Bimini strap/mount points.
- Bimini should be laid down on back deck/floor for travel.
- Speeds while top is open or in the up/stowed position is 25 MPH max, this is not assessed with high wind speeds, and in the end best judgement must be used when winds or waters are rough. General rule of thumb is, if it is rattling around take the top down, or reduce the speed of the boat.
- We suggest tightening the bimini and boat-mounted hardware, and are checked 1-2 times per season: spring/fall, for trailering can back set screws out.
- If rear stanchion legs are installed, be sure to use provided stanchion clips to keep stanchion legs from swinging around inside boat, when not in use.

Fishing/Convertible/Sun- Tops

- Make sure all snaps are secured when boating with top up, with the exception of walkthrough zippers.
- If top snaps seems tight to reach, release tension of top by releasing back stanchion leg, finishing the snaps on windshield, and then stretching top to secure stanchion leg, depending on material , user may have to pull on the frame work to secure stanchion in place

CLEANING & CARE

- Prevent water from pooling on top for long periods when being stored, or in the opened position.
- Do not store your top wet or allow water to stand inside your boat as moisture will be trapped inside and mold/mildew can grow on your top/upholstery and other areas of your boat.
- DO NOT fold your enclosure panels, to keep the wrinkles to a minimum we ask that they be rolled, the material can be folded to the clear curtains.
- To clean material– using a mild soap (like dish detergent) and water solution with a wash mitt, rinse and allow to dry. We have cleaners available for this purpose at our location.
- To clean clear vinyl: a clear vinyl polish is highly recommended; Plexus or Dr. P's clear vinyl cleaner are names for cleaners, others can be picked up at an outdoor stores, sure NOT to use any products with ammonia in them, NO WINDEX!!!!
- Always replace & repair your top promptly if damage occurs.

WARNING! Provide adequate ventilation when operating engine with canvas installed. Harmful undetectable gases may be present.

WARRANTY

- Boat covers and boat tops carry a two year workmanship warranty.
- Fabrics may carry an additional manufacturer's warranty.
- Boat tops must be properly secured for travel using all thumbscrews or set pins. Tops are to be secured for use on water at a **maximum speed of 25 mph**. Tops & Enclosures are **not** intended for road travel.
- Warranty does not cover rubbing, wear marks, mold/mildew on boat, motor or upholstery.
- This warranty does not cover damages due to misuse, negligence, vandalism, or acts of nature, including but not limited to wind, hail, lightning, rain, or snow.